



Tech Note

DETAIL

In cases where an M1-G main board fails to power up normally, the **17VDC** power supply can be connected as shown in Fig 2. (power supply negative to AUX NEG)

Note. An M1 board failing to power up may be caused by normal variations in component tolerances in the power supply or the M1 board. Connecting the power supply as per Fig 2. will remedy the issue in most cases.





Rev 1.0 Dec21



Innovative Electronic Solutions www.ness.com.au





